

WRB w/ drainage channels - joints lapped and taped (DuPont™ Tyvek® Tape)

Mesh screen at top of wall over cross-vented batten

Mesh screen at window head

Window installed per best practice sequence - after WRB

DuPont™ RainVent™ Batten placed over WRB

DuPont™ Tyvek® HomeWrap® or DuPont™ Tyvek® StuccoWrap®

DuPont™ Tyvek® WrapCaps

Mesh screen at wall base over cross-vented batten (allows air flow through)

WRB over-lapped over base flashing (skip taped or fully taped)

DuPont™ Flashing Tape seals joint at base of wall

