

WRB - joints lapped and taped
(DuPont™ Tyvek® Tape)

Mesh screen at top
of wall over cross-
vented batten

Mesh screen at
window head

WRB (DuPont™ Tyvek®
HomeWrap®, Grade D building
paper, building felt)

Metal lathe

Stucco scratch coat

Stucco final coat

Window installed per best
practice sequence - after WRB

Jamb extension- provide 1" gap
between foam and window

DuPont™ RainVent™
Batten placed over WRB

DuPont™ Tyvek®
HomeWrap® or DuPont™
Tyvek® StuccoWrap®

DuPont™ Tyvek® WrapCaps

Exterior continuous insulation

DuPont™ Flashing Tape
seals joint at base of wall

Mesh screen at wall base
over cross-vented batten
(allows air flow through)

WRB over-lapped over
base flashing
(skip taped or fully taped)

