



**NOTE**

- 1) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- 2) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, REGULATIONS AND LAWS TO DETERMINE THE APPROPRIATE CONSTRUCTION METHODS AND MATERIALS NEEDED.

SCALE: NOT TO SCALE  
 REVISION DATE: 4/28/10  
 DRAWING: FA-BX-W200s

**STOREFRONT WINDOW SILL - METHOD 1**  
 BRICK VENEER / EXTERIOR INSULATION / STEEL STUD WALL / FLUID APPLIED FLASHING



**Tyvek.**  
 FLUID APPLIED WB