



NOTE

- 1) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- 2) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, REGULATIONS AND LAWS TO DETERMINE THE APPROPRIATE CONSTRUCTION METHODS AND MATERIALS NEEDED.

SCALE: NOT TO SCALE
 REVISION DATE: 4/28/10
 DRAWING: FA-BX-W201s

STOREFRONT WINDOW SILL - METHOD 2
 BRICK VENEER / EXTERIOR INSULATION / STEEL STUD WALL / SELF-ADHERED FLASHING



Tyvek.
 FLUID APPLIED WB