



INSTALL TOWER® RESIDENTIAL SEALANT OR RECOMMENDED SEALANT (AND BACKER ROD AS NECESSARY) AROUND THE WINDOW OPENING AT THE INTERIOR. IT IS ALSO ACCEPTABLE TO USE GREAT STUFF PRO™ WINDOW & DOOR POLYURETHANE FOAM SEALANT, OR RECOMMENDED FOAM

TYPICAL WALL ASSEMBLY

- FINISH COAT
- BASE COAT w/ EMBEDDED REINFORCING MESH
- RIGID INSULATION
- DUPONT™ TYVEK® WRB¹
- OSB SHEATHING
- WOOD STUDS w/ BATT INSULATION
- VAPOR RETARDER²
- GYPSUM BOARD

TAPE THROUGH-WALL FLASHING TO SHEATHING USING DUPONT™ FLEXWRAP™

LAP 6" AND TAPE TYVEK® WRB OVER THROUGH WALL FLASHING USING FLEXWRAP™

METAL LINTEL

SEALANT

WINDOW WITH INTEGRAL MOUNTING FLANGE

¹REFER TO THE *FACADE CONSIDERATIONS* SECTION OF THE APPLICABLE DUPONT INSTALLATION GUIDELINES TO HELP DETERMINE THE APPROPRIATE TYVEK® WRB FOR THE CLADDING TYPE.

²USE OF INTERIOR VAPOR RETARDER IS DEPENDENT UPON CLIMATE ZONE AND LOCAL BUILDING CODES AND LAWS. CONSULT LOCAL JURISDICTION TO ENSURE APPROPRIATE USE OF VAPOR RETARDERS IN WALL ASSEMBLY.

NOTES:

- TAPE ALL TYVEK® WRB SEAMS WITH DUPONT™ TYVEK® TAPE.
- FLASH ALL PENETRATIONS WITH DUPONT SELF-ADHERED FLASHING PRODUCTS.
- FASTEN TYVEK® WRB TO SHEATHING WITH APPROVED FASTENERS AND CORRECT SPACING OF WRAP CAP STAPLES/NAILS (ex. DUPONT™ TYVEK® WRAP CAP FASTENERS).
- DO NOT APPLY TYVEK® TAPE OR DUPONT SELF-ADHERED FLASHING PRODUCTS OVER TYVEK® WRAP CAP FASTENERS, OR RECOMMENDED FASTENERS; HOWEVER, FASTENERS CAN BE INSTALLED OVER THE FLASHING.
- SEAL OR GASKET BRICK TIES AT THE FACE OF TYVEK® WRB.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERNS OVER MATERIAL SELECTION (ex. SHEATHING TYPE, FRAMING SIZE, INSULATION THICKNESS, ETC.) DETAILING SHOWN ABOVE.
- INSTALL EIFS ACCORDING TO MANUFACTURER'S WRITTEN INSTRUCTIONS.



SCALE: NOT TO SCALE

REVISION DATE: 4/29/2022

DRAWING: A77

WINDOW HEAD DETAIL

RESIDENTIAL WOOD FRAME STRUCTURE w/ EIFS CLADDING