



## BRICK - WALL PENETRATION (METHOD 1)

- SEAL ALL **DUPONT™ TYVEK®** SEAMS AND REPAIR MINOR HOLES WITH **DUPONT™ TYVEK®** TAPE.
- FASTEN **DUPONT™ TYVEK®** WITH APPROVED FASTENERS AND SPACING.
- INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.
- EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND **DUPONT™ TYVEK®** LAYER.



**Tyvek.**