



## EIFS - CONCRETE COLUMN TRANSITION (METHOD 2)

- SEAL ALL DUPONT™ TYVEK® SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.
- FASTEN DUPONT™ TYVEK® WITH APPROVED FASTENERS AND SPACING.
- INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.



Tyvek.