

1) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.

2) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, ${\tt REGULATIONS~AND~LAWS~TO~DETERMINE~THE~APPROPRIATE~CONSTRUCTION~METHODS~AND~MATERIALS~NEEDED.}\\$

SCALE: NOT TO SCALE

REVISION DATE: 4/28/10

DRAWING: FA-BX-W103s

FLANGED WINDOW SILL - METHOD 2

Tyvek. BRICK VENEER / EXTERIOR INSULATION / CMU WALL / SELF-ADHERED FLASHING FLUID APPLIED WB