

1) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.

2) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES,  ${\tt REGULATIONS~AND~LAWS~TO~DETERMINE~THE~APPROPRIATE~CONSTRUCTION~METHODS~AND~MATERIALS~NEEDED.}\\$ 

> Tyvek. FLUID APPLIED WB

SCALE: NOT TO SCALE

FLANGED WINDOW SILL - METHOD 1

REVISION DATE: 9/14/10 DRAWING: FA-S-W202s

STUCCO / STEEL STUD WALL / FLUID APPLIED FLASHING