

- 1) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- 2) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, ${\tt REGULATIONS~AND~LAWS~TO~DETERMINE~THE~APPROPRIATE~CONSTRUCTION~METHODS~AND~MATERIALS~NEEDED.}\\$

SCALE: NOT TO SCALE

REVISION DATE: 9/14/10

DRAWING: FA-S-W203s

FLANGED WINDOW SILL - METHOD 2

STUCCO / STEEL STUD WALL / SELF-ADHERED FLASHING

