

DuPont™ Entira™ SD100

Entira™ AS resins Product Data Sheet

Description

Product Description DuPont™ Entira™ AS SD100 is an extremely hygroscopic ionomer resin that is supplied as free flowing pellets.

Restrictions

Material Status Commercial: Active

Typical Characteristics

Uses Industrial Applications; Packaging

Features Entira™ AS SD100 is used to lower the static decay time and surface resistivity of LDPE, LLDPE and other polymers.

Characteristics / Benefits Entira™ AS SD100 can be precompounded or dry blended into polymers for extrusion, molding, or various other processing methods

Applications Antistatic agent for polyethylene (LDPE, LLDPE and EVA) and other polymers, in films, moldings and extruded forms

Typical Properties

Physical	Nominal Values	Test Method(s)	
*Density ()	0.985 g/cm ³	ASTM D792	ISO 1183
*Melt Flow Rate (190°C/2.16kg)	5.0 g/10 min	ASTM D1238	ISO 1133
Thermal	Nominal Values	Test Method(s)	
*Melting Point (DSC)	92 °C (197.6 °F)	ASTM D3418	ISO 3146
Freezing Point (DSC)	64 °C (147.2 °F)	ASTM D3418	ISO 3146
Vicat Softening Point ()	63 °C (145.4 °F)	ASTM D1525	ISO 306

Processing Information

*Maximum Processing Temperature 210 °C (410 °F)

General Processing Information Entira™ AS SD100 is a hygroscopic material. To minimize exposure to moisture, any remaining material should be hermetically sealed in a barrier package immediately after use. In order to reuse remaining material that has been hermetically sealed, the material should be dried under vacuum with a nitrogen flow at 50–60°C for several hours prior to use. Entira™ AS SD100 is available in pellet form for use in conventional equipment for processing polyolefins. Entira™ AS SD100 can be fed together with base polymers and other additives in the hopper during processing. Typical addition levels range from 10-30%.

Materials of construction used in the processing of this resin should be corrosion resistant. Stainless steels of the types 316, 15-5PH, and 17-4PH are excellent, as is quality chrome or nickel plating, and in particular duplex chrome plating. Type 410 stainless steel is satisfactory, but needs to be tempered at a minimum temperature of 600°C (1112°F) to avoid hydrogen-assisted stress corrosion cracking. Alloy steels such as 4140 are borderline in performance. Carbon steels are not satisfactory. While stainless steels can provide adequate corrosion protection, in some cases severe purging difficulties have been encountered. Nickel plating has been satisfactory, but experiments have shown that chrome surfaces have the least adhesion to acid based polymers. In recent years, the quality of chrome plating has been deteriorating due to environmental pressures, and the corrosion protection has not always been adequate. Chrome over top of stainless steel seems to provide the best combination for corrosion protection and ease of purging.

After processing Entira™ AS, purge the material out using a polyethylene resin, preferably with a lower

melt flow rate than the Entira™ AS resin in use.

The "Disco Purge Method" is suggested as the preferred purging method, as this method usually results in a more effective purging process. Information on the Disco Purge Method can be obtained via your DuPont Sales Representative.

Never shut down the extrusion system with Entira™ AS in the extruder and die. Properly purge out the Entira™ AS with a polyethylene, and shut down the line with polyethylene or polypropylene in the system.

FDA Status Information

DuPont™ ENTIRA™ AS SD100 Resin complies with Food and Drug Administration Regulation 21 CFR 177.1330(a) - Ionomeric resins, subject to the limitations and requirements therein. DuPont™ ENTIRA™ AS SD100 Resin may be used in contact with non-alcoholic food, subject to the finished food-contact article meeting the extractive limitations under the intended conditions of use, as shown in 21 CFR 177.1330(d).

Regulatory Information

For information on regulatory compliance outside of the U.S., consult your local DuPont representative.

Safety & Handling

For information on appropriate Handling & Storage of this polymeric resin, please refer to the Material Safety Data Sheet..

A Product Safety Bulletin, Material Safety Data Sheet, and/or more detailed information on extrusion processing and/or compounding of this polymeric resin for specific applications are available from your DuPont Packaging and Industrial Polymers representative.

Regional Centres

DuPont operates in more than 70 countries.

For help finding a local representative, please contact one of the following regional customer contact centers:

Americas

DuPont Company
Chestnut Run Plaza – Bldg. 730
974 Centre Road
Wilmington, Delaware
19805 U.S.A.
Toll-Free (USA): 1-800-628-6208
Telephone: 1-302-774-1000
Fax: 1-302-355-4013

DuPont do Brasil, S.A.
Alameda Itapecuru, 506
06454-080 Barueri, SP Brasil
Telephone: +55 11 4166 8000
Fax: +55 11 4166 8736

Asia Pacific

DuPont China Holding Co., Ltd.
Shanghai Branch
399 Keyuan Road, Bldg. 11
Zhangjiang Hi-Tech Park
Pudong New District, Shanghai
P.R. China (Postcode: 201203)
Telephone +86 21 3862 2888
Fax +86-21-3862-2889

Europe / Middle East / Africa

DuPont de Nemours Int'l. S.A.
2,Chemin du Pavillon Box 50
CH-1218 Le Grand Saconnex
Geneva, Switzerland
Telephone +41 22 717 51 11
Fax +41 22 717 55 00

<http://www.dupont.com>

The data listed here fall within the normal range of properties, but they should not be used to establish specification limits nor used alone as the basis of design. The DuPont Company assumes no obligations or liability for any advice furnished or for any results obtained with respect to this information. All such advice is given and accepted at the buyer's risk. The disclosure of information herein is not a licence to operate under, or a recommendation to infringe, any patent of DuPont or others. Since DuPont cannot anticipate all variations in actual end-use conditions, DuPont makes no warranties and assumes no liability in connection with any use of this information.

CAUTION: Do not use DuPont materials in medical applications involving implantations in the human body or contact with internal body fluids or tissues unless the material has been provided from DuPont under a written contract that is consistent with DuPont policy regarding medical applications and expressly acknowledges the contemplated use. For further information, please contact your applications and expressly acknowledges the contemplated use. For our DuPont representative You may also request a copy of DuPont POLICY Regarding Medical Applications H-50103-3 and DuPont CAUTION Regarding Medical Applications H-50102-3.

Copyright © 2009 DuPont. The DuPont Oval Logo, DuPont™, The miracles of science™, and trademarks designated with "®" are registered trademarks or trademarks of E.I. du Pont de Nemours and Company or its affiliates. All rights reserved

Copyright© 2016 DuPont. All Rights Reserved. The DuPont Oval, DuPont™, The miracles of science™ and all products denoted with ™ or ® are trademarks or registered trademarks of DuPont and or its affiliates. Internet/Intranet usage via DuPont facilities is to be used primarily for DuPont business.