



DUPONT™ 4899R

SOLDERABLE SILVER TERMINATION

PRODUCT DESCRIPTION

DuPont™ 4899R is a solderable cadmium-free* and lead-free* silver termination for lead attachment to multilayer capacitors. This product has good solderability and high adhesion over a wide range of capacitor bodies. This termination may be employed on parts where platable terminations are not desired but which will be subjected to soldering conditions.

PRODUCT BENEFITS

- Phthalate and cadmium and lead free*
- Good adhesion and solderability
- Dip even large size parts without a blot

*Phthalate, cadmium and lead "free" as used herein means that phthalate, cadmium and lead are not an intentional ingredients in and are not intentionally added to the referenced product. Trace amounts however may be present.

PROCESSING

Application

Carrier plate-type dipping

Substrates

Ceramic capacitors bodies

Typical Drying Conditions

160-180°C peak, 15 minute cycle on belt dryer

Typical Firing

850°C for 10 minutes at peak, 40 minute cycle

Table 1-Typical Physical Properties

Test	Properties
Solids (150°C) [%]	74.5 - 76.5
Viscosity (Pa.s) [Brookfield RVT, 14/6R @ 10 rpm, 25°C]	40 - 60
Thinner	DuPont™ 4553

This table shows anticipated typical physical properties for DuPont™ 4899R based on specific controlled experiments in our labs and are not intended to represent the product specifications, details of which are available upon request.

Dipping

DuPont™ 4899R termination should be thoroughly mixed before use. This is best achieved by slow, gentle hand stirring with a clean, burr-free spatula (flexible plastic or stainless steel) for 1-2 minutes, or by slow jar rolling for 24 hours. Dipping should be carried out in a clean, well-ventilated area. Note: optimum dipping characteristics of DuPont™ 4899R are generally achieved in the temperature range of 21°C-25°C.

Firing

Care must be taken to ensure that any gases/vapors from other chemicals or materials (e.g. halogenated solvents) do not enter the furnace muffle. It is also essential that the air supply to the furnace is clean, dry and free of contaminants. Air flows and extraction rates should be optimized to ensure that oxidizing conditions exist within the muffle, and that no furnace exhaust gases enter the room. DuPont™ 4899R termination composition is fired on a 40 minute firing cycle to a peak of 850°C, held for 10 minutes. Variations in the peak firing temperature and/or time at the peak temperature (e.g. 850-900°C for 5-10 minutes at peak can be considered) may result in variations in the final fired properties. Care must be taken to assess the appropriate firing conditions for a particular body type.

Thinner

DuPont™ 4899R is optimized for dipping and thinning is not normally required. DuPont™ 4553 may be used sparingly for slight adjustments to viscosity or to replace evaporation losses. However, the use of too much thinner or the use of a non-recommended thinner may affect the rheological behavior of the material and its dipping characteristics.



DUPONT™ 4899R SOLDERABLE SILVER TERMINATION

STORAGE AND SHELF LIFE

Containers should be stored, tightly sealed, in a clean, stable environment at room temperature (<25°C). Shelf life of material in unopened containers is six months from date of shipment. Some settling of solids may occur and compositions should be thoroughly mixed prior to use.

SAFETY AND HANDLING

For Safety and Handling information pertaining to this product, read the Material Safety Data Sheet (MSDS).

FOR MORE INFORMATION ON DUPONT™ 4899R OR OTHER DUPONT MICROCIRCUIT MATERIALS, PLEASE CONTACT YOUR LOCAL REPRESENTATIVE:

Americas

DuPont Microcircuit Materials
14 TW Alexander Drive
Research Triangle Park, NC 27709
USA
Tel +1 800 284 3382 (calls within USA)
Tel +1 919 248 5188 (calls outside USA)

Europe, Middle East & Africa

Du Pont (UK) Ltd
Coldharbour Lane
Bristol BS16 1QD
UK
Tel +44 117 931 3191

Asia

Du Pont Kubushiki Kaisha
MCM Technical Lab
DuPont Electronics Center
KSP R&D B213, 2-1,
Sakado 3-chome, Takatsu-ku,
Kawasaki-shi, Kanagawa, 213-0012
Japan
Tel +81 44 820 7575

DuPont Taiwan Ltd
45, Hsing-Pont Road
Taoyuan, 330
Taiwan
Tel +886 3 377 3616

DuPont China Holding Company Ltd
Bldg. 11, 399 Keyuan Road
Zhangjiang Hi-Tech Park
Pudong New District
Shanghai 201203
Tel +86 21 3862 2888

DuPont Korea Inc.
3-5th Floor, Asia tower #726
Yeoksam-dong, Gangnam-gu
Seoul 135-719, Korea
Tel +82 2 2222 5275

E.I. DuPont India Private Limited
7th Floor, Tower C, DLF Cyber Greens
Sector-25A, DLF City, Phase-III
Gurgaon 122 002 Haryana, India
Tel +91 124 409 1818

Du Pont Company (Singapore) Pte Ltd
1 HarbourFront Place, #11-01
HarbourFront Tower One
Singapore 098633
Tel +65 6586 3022

mcm.dupont.com

Copyright © 2015 DuPont. All rights reserved. The DuPont Oval Logo, DuPont™, and all DuPont products denoted with ® or ™ are registered trademarks or trademarks of E. I. du Pont de Nemours and Company or its affiliates.

This information corresponds to our current knowledge on the subject. It is offered solely to provide possible suggestions for your own experiments. It is not intended, however, to substitute for any testing you may need to conduct to determine for yourself the suitability of our products for your particular purposes. This information may be subject to revision as new knowledge and experience becomes available. Since we cannot anticipate all variations in end-use conditions, DuPont makes no warranties, and assumes no liability in connection with any use of this information. Nothing in this publication is to be considered as a license to operate under or a recommendation to infringe any patent right.

CAUTION: Do not use in medical applications involving permanent implantation in the human body. For other medical applications, see "DuPont Medical Caution Statement," H-50102-5 K-28873 (5/15)