

Tech Fact

Ion Exchange Resins Selectivity

Introduction

Ion exchange resins, when placed in a solution, reach an equilibrium state between ions in the solution and ions on the resin. From this equilibrium state, selectivity coefficients (equilibrium constants) can be defined based on the ratios of ions in the solution vs. ions on the resin.

These selectivity coefficients are a measurement of a resins preference for an ion. The greater the selectivity coefficient, the greater the preference for the ion.

This document presents the **relative affinity values** of resins for different ions, the affinity of the cation resins for the H⁺ ion and the affinity of the anion resins for the OH⁻ ion being defined arbitrarily as 1.0.

For example, a styrenic strong acid cation resin with 8% DVB cross–linking has a relative affinity for sodium vs. hydrogen of 1.56, while the selectivity for calcium vs. hydrogen is 4.06. As a result, calcium is selectively removed by the ion exchange resin over sodium.

In column operation, undesirable ions can be selectively removed by regenerating the resin with any ion of lower selectivity. For example, calcium can be removed from a solution by a strong acid cation resin when the resin is regenerated using salt (Na-cycle operation) or acid (H-cycle operation).

Selectivity coefficients can also be used to determine the order of elution in column operation. In a demineralizer (H-cycle operation), sodium with a relative affinity of 1.56 will elute before ammonium with an affinity of 2.01, which is followed by potassium, with an affinity of 2.28.

lonic leakage from demineralizers can also be predicted by the use of selectivity coefficients. With a knowledge of the degree of regeneration, solution pH and the relative affinity value, an estimate of the ionic leakage can be calculated.

For a complete treatment of the subject, numerous textbooks can be consulted. One excellent reference is lon Exchange, by Friedrich Helfferich, published by Dover Press under ISBN #61-15453.

SAC resins selectivity coefficients

Relative affinities of various cations (compared with the hydrogen ion) on sulfonated polystyrene cation exchange resins with different degrees of cross-linking.

Percentage of	cross-linking of th	ne conolymer
reiceillaue oi	C1055*	ie condivillei

	reicentage of cross-linking of the copolymer				
Cation	4% DVB	8% DVB	10% DVB	16% DVB	
Li+	0.76	0.79	0.77	0.68	
H+	1.00	1.00	1.00	1.00	
Na⁺	1.20	1.56	1.61	1.62	
NH ₄ +	1.44	2.01	2.15	2.27	
K+	1.72	2.28	2.54	3.06	
Rb⁺	1.86	2.49	2.69	3.14	
Cs+	2.02	2.56	2.77	3.17	
Ag⁺	3.58	6.70	8.15	15.6	
TI+	5.08	9.76	12.6	19.4	
UO ₂ ²⁺	1.79	1.93	2.00	2.27	
Mg ²⁺	2.23	2.59	2.62	2.39	
Zn ²⁺	2.37	2.73	2.77	2.57	
Co ²⁺	2.45	2.94	2.92	2.59	
Cu ²⁺	2.49	3.03	3.15	3.03	
Cd ²⁺	2.55	3.06	3.23	3.37	
Ni ²⁺	2.61	3.09	3.08	2.76	
Ca ²⁺	3.14	4.06	4.42	4.95	
Sr ²⁺	3.56	5.13	5.85	6.87	
Pb ²⁺	4.97	7.80	8.92	12.2	
Ba ²⁺	5.66	9.06	9.42	14.2	

SBA resins selectivity coefficients

Relative affinities of various anions (compared with the hydroxide ion) on polystyrenic strongly basic anion exchange resins, both Type 1 and Type 2.

lon	Type 1	Type 2
OH-	1.0	1.0
Benzene sulfonate	500	75
Salicylate	450	65
Citrate	220	23
-	175	17
Phenate	110	27
HSO ₄ -	85	15
CIO ₃ -	74	12
NO ₃ -	65	8
Br-	50	6
CN-	28	3
HSO ₃ -	27	3
BrO ₃ -	27	3
NO ₂ -	24	3
CI-	22	2.3
HCO₃⁻	6.0	1.2
IO ₃ -	5.5	0.5
Formate	4.6	0.5
Acetate	3.2	0.5
Propionate	2.6	0.3
F-	1.6	0.3
HSiO₃ ⁻	< 1.0	< 1.0
H ₂ PO ₄ -	5.0	0.5

The reason for mentioning benzene sulfonate in the preceding list is that it is an example of synthetic surfactants frequently found in water. The very strong affinity of the resins for this compound results in a high risk of resin fouling.

WAC resins

The selectivity data is less significant for weak acid cation exchange resins, which operate (in the H⁺ form) only with feed water containing alkalinity. In addition, selectivity values are less well documented for these resins. However, approximate data is available as follows, with calcium as the reference ion:

Cation	
Mg ²⁺	0.3
Sr ²⁺	< 1
Ba ²⁺	< 1
Ca ²⁺	1.0
Cd ²⁺	1.0
Ni ²⁺	1.4
Zn ²⁺	1.5
Co ²⁺	1.9
Cu ²⁺	2.0
Pb ²⁺	> 1

It is important to know that weak acid resins do not have a high affinity for strontium and barium, so that in operation, these ions may leak before calcium into the treated water.

For more information, contact our Customer Information Group:

Asia Pacific Europe, Middle East, Africa +86 21 3851 4988 +31 115 672626

Latin America +55 11 5184 8722 North America 1-800-447-4369

www.dowwaterandprocess.com

WARNING: Oxidizing agents such as nitric acid attack organic ion exchange resins under certain conditions. This could lead to anything from slight resin degradation to a violent exothermic reaction (explosion). Before using strong oxidizing agents, consult sources knowledgeable in handling such materials.

NOTICE: No freedom from infringement of any patent owned by Dow or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, Customer is responsible for determining whether products and the information in this document are appropriate for Customer's use and for ensuring that Customer's workplace and disposal practices are in compliance with applicable laws and other government enactments. The product shown in this literature may not be available for sale and/or available in all geographies where Dow is represented. The claims made may not have been approved for use in all countries. Dow assumes no obligation or liability for the information in this document. References to "Dow" or the "Company" mean the Dow legal entity selling the products to Customer unless otherwise expressly noted. NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.

All information set forth herein is for informational purposes only. This information is general information and may differ from that based on actual conditions. Please note that physical properties may vary depending on certain conditions and while operating conditions stated in this document are intended to lengthen product lifespan and/or improve product performance, it will ultimately depend on actual circumstances and is in no event a guarantee of achieving any specific results. Nothing in this document should be treated as a warranty by Dow.

