


# DuPont wearable medical device solutions portfolio

Including technologies from DuPont™ Liveo™, DuPont™ Pyralux®, DuPont™ Kapton® and DuPont™ Laird™



## DuPont™ Liveo™, DuPont™ Pyralux® and DuPont™ Laird™ technologies meet wearable medical device challenges

### DuPont™ Liveo™ Soft Skin Adhesives

- Lightly crosslinked silicone elastomeric thermoset adhesives
- Useful for wearable monitoring device attachment to skin: gentle, skin-friendly adhesion; repositionable; gentle removal from skin
- Example: Liveo™ MG 7-9960 Soft Skin Adhesive

### DuPont™ Liveo™ Pressure Sensitive Adhesives

- Silicone resin adhesives with high adhesion and skin conformity; non-irritating/non-sensitizing to skin
- Useful for long-term wearable medical device attachment to skin
- Example: Liveo™ MG-2402 Pressure Sensitive Adhesive

### DuPont™ Liveo™ Liquid Silicone Rubbers & DuPont™ Liveo™ Low-Consistency Rubbers

- Low-viscosity thermoset silicone elastomers
- Ideal for intricate designs and close tolerance parts; can be used for spacers, sheets, housing or protection
- Example: Liveo™ MDX4-4210 Liquid Silicone Rubber

### DuPont™ Liveo™ High-Consistency Rubbers

- Extrudable thermoset silicone elastomer
- Can be used for spacers, sheets, housing or protection

### DuPont™ Liveo™ Film technology

- Clear silicone extruded films
- Used as base or protective film
- Example: Liveo™ 7-4107 Silicone Membrane

### DuPont™ Liveo™ Soft Skin Conductive Tape

- Electrically conductive silicone thermoset adhesive interface material
- Used for continuous high-quality signal transfer and comfortable wear on skin
- Example: Liveo™ Soft Skin Conductive Tape 1-3150

### DuPont™ Pyralux® AP

- All-polyimide double-sided copper-clad laminate
- Industry standard in terms of thermal, chemical and mechanical properties
- Ideal for use in rigid flex and multilayer flex applications that require advanced performance and high reliability in flexible printed circuit

### DuPont™ Laird™ Precision Structural Metals

- Custom precision metals
- Needs such as battery contact and thermal interface materials are met by leveraging the brand's end-to-end engineering expertise and flexibility

### DuPont™ Laird™ Spectrum Laser Processing

- Precision laser processing and ablation of subcutaneous electrodes and thin films for patient-monitoring devices

### For more information about Liveo™ solutions for smart wearable devices

Visit [liveo.dupont.com](https://liveo.dupont.com) – or scan the QR code at right to be taken directly to our wearable medical device solutions web page, where you'll find details on the full portfolio of Liveo™ Silicone Skin Adhesives and Liveo™ Silicone Elastomers.



To learn more about DuPont™ Liveo™ Healthcare Solutions, visit [liveo.dupont.com](https://liveo.dupont.com).



Smarter Healthcare.  
Positive Patient Outcomes.

DuPont™, the DuPont Oval Logo, and all trademarks and service marks denoted with ™, SM or ® are owned by affiliates of DuPont de Nemours, Inc. unless otherwise noted. Teflon™ is a trademark of The Chemours Company FC, LLC.  
© 2023 DuPont.

The information set forth herein is furnished free of charge and is based on technical data that DuPont believes to be reliable and falls within the normal range of properties. It is intended for use by persons having technical skill, at their own discretion and risk. This data should not be used to establish specification limits nor used alone as the basis of design. Handling precaution information is given with the understanding that those using it will satisfy themselves that their particular conditions of use present no health or safety hazards. Since conditions of product use and disposal are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information. As with any product, evaluation under end use conditions prior to specification is essential. Nothing herein is to be taken as a license to operate or a recommendation to infringe on patents.

Caution: Do not use DuPont materials in medical applications involving implantation in the human body or contact with internal body fluids or tissues unless the material has been provided from DuPont under a written contract that is consistent with DuPont policy regarding medical applications and expressly acknowledges the contemplated use. The customer is solely responsible to determine whether DuPont products are suited for customer's intended purpose or application and may contact DuPont technical experts for more product details prior to sourcing products. DuPont disclaims liability for any incidental or consequential damages resulting from customer's use of DuPont products. For further information, please contact your DuPont representative. You may also request a copy of DuPont POLICY Regarding Medical Applications H-50103-4 and DuPont CAUTION Regarding Medical Applications H-50102-4.