

PRODUCT DATA

AURUM[®] JCN3030 Thermoplastic Polyimide

TYPICAL PROPERTIES	TEST METHOD	UNITS	VALUE	
PHYSICAL				
Specific Gravity	ASTM D-792	-	1.42	
Filler Content	-	%	30	
Mold Shrinkage	-	%	0.25	
Water Absorption 24 hrs @ 73°F	ASTM D-570	%	0.23	
MECHANICAL				
Tensile Strength	73°F 300°F	ASTM D-638 "	psi (MPa) "	33,300 (229) 20,500 (144)
Elongation	73°F 300°F	ASTM D-638 "	% "	2 4
Flexural Strength	73°F 300°F	ASTM D-790 "	psi (MPa) "	45,600 (314) 31,300 (216)
Flexural Modulus	73°F 300°F	ASTM D-790 "	psi (MPa) "	2,500,000 (17,200) 2,200,000 (15,160)
Izod Impact Strength (notched)		ASTM D-256	ft lb/in (J/m)	2.0 (110)
Compressive Strength	73°F 300°F	JIS K-7208 "	psi (MPa) "	30,000 (207) 14,800 (102)
THERMAL				
Melt Point		DSC	°F (°C)	730 (388)
Glass Transition Temperature		DSC	°F (°C)	482 (250)
Melt Flow Index (788°F/ 22 lbs.)		ASTM D-1238	g/10 min	27~37
Coefficient of Thermal Expansion		ASTM D-696	10 ⁻⁵ / °F (10 ⁻⁵ / °C)	.33MD / 2.6TD (0.6MD / 4.7TD)
Heat Deflection Temperature		ASTM D-648	°F (°C)	478 (248)

DESCRIPTION

AURUM JCN3030 is a high-performance polyimide for precision injection molded components and extruded products. A member of the AURUM family of advanced engineering resins, carbon fiber reinforced AURUM JCN3030 offers a unique balance of mechanical, thermal, and tribological properties for outstanding performance in demanding automotive, business machinery, industrial equipment, aerospace, and semiconductor equipment applications. AURUM components offer excellent mechanical strength and toughness, dimensional stability, low outgassing, and exceptional radiation resistance. In addition, AURUM exhibits outstanding resistance to hydraulic, automotive, and many industrial fluids and solvents, a low coefficient of thermal expansion, creep resistance, and flame retardancy. AURUM JCN3030 withstands high PV levels and provides a low wear factor and low friction surface over a broad temperature range in both dry and lubricated environments.

Mitsui Chemicals Inc., Technical Data Sheet N.961001

INJECTION MOLDING

AURUM JCN3030 can be readily injection molded in most reciprocating screw injection molding machines. AURUM resin pellets should be dried prior to melt processing on trays in an air circulation oven or desiccating hopper dryer under the following conditions: 8 hours at 428°F, 10 hours at 392°F, or 12 hours at 356°F. Cylinder temperature requirements range from 720 - 806°F. Injection pressures of 11,000 - 35,000 psi, nominal back pressures of 0-50 psi, medium to high injection velocities, and screw speeds of 100 - 200 rpm are utilized for AURUM injection molding. Mold temperatures range from 356 - 410°F. AURUM sprue and runner systems can be ground and mixed with virgin AURUM resin at 15% - 30% levels without significant loss of mechanical or wear properties for enhanced economies. AURUM can be easily purged with unfilled or glass fiber reinforced polyethersulfone, polysulfone, or polyetherimide. AURUM can be injection molded with select outer-heating design hot runner systems.

APPLICATIONS

AURUM JCN3030 components are excellent replacements for metals, ceramics, and other plastics. High-performance AURUM parts include: thrust washers and oil seal rings for automotive and off road vehicle transmissions, thermal insulators and stripper fingers for high-speed copiers, jet engine components, check valve balls, spline couplings, heat-resistant gears, vanes, wear strips, and valve seats. Other AURUM applications include carriers for aluminum hard disks and silicon wafers, journal bearings, and bearing retainers.

CAUTION! DO NOT USE AURUM®(A) IN MEDICAL APPLICATIONS INVOLVING IMPLANTATION IN THE HUMAN BODY OR (B) IN CONTACT WITH INTERNAL BODY FLUIDS OR TISSUES. AURUM® WAS NOT DESIGNED OR MANUFACTURED FOR SUCH PURPOSES.

NO REPRESENTATION, PROMISE, EXPRESS WARRANTY OR IMPLIED WARRANTY IS MADE CONCERNING THE SUITABILITY OF AURUM® FOR USE IN IMPLANTATION IN THE HUMAN BODY OR IN CONTACT WITH INTERNAL BODY FLUIDS OR TISSUES.

AURUM® IS NOT RECOMMENDED, AUTHORIZED OR APPROVED FOR IMPLANTS. CLINICAL TESTING HAS NOT BEEN CONDUCTED TO DETERMINE THE SUITABILITY OF AURUM® FOR IMPLANTATION. Because all implantable medical devices carry risk of failure and resulting adverse consequences, such testing should be conducted before and such implantation occurs to determine the effectiveness and safety of such use. Approval has neither been sought, nor received, from the FDA or any other governmental authority for use of AURUM® in implantation in the human body or in contact with internal body fluids or tissues.

DO NOT MAKE REFERENCE TO THE AURUM® NAME OR TRADEMARK OR TO THE NAME OF MANUFACTURER OR OTHER SUPPLIER OF AURUM® IN ASSOCIATION WITH AN APPLICATION MEDICAL DEVICE.

IMPORTANT: Technical information contained herein is furnished without charge or obligation, and is given and accepted at recipient's sole risk. Because conditions of use may vary and are beyond our control, MTC makes no representation about, and is not responsible or liable for the accuracy or reliability of data, nor for toxicological effects or industrial hygiene requirements associated with particular uses of any product described herein. Nothing contained in this bulletin shall be considered a recommendation for any use that may infringe patent rights or an endorsement of any particular material not supplied by MTC. The "Properties" and "Applications" listed in this bulletin are not specifications. They are provided as information only and in no way modify, amend or enlarge and specification or warranty.

AURUM is a registered trademark of Mitsui Chemicals, Inc.