



- ROOF**
- ROOFING SHINGLES
 - MEMBRANE TYPE EAVE PROTECTION (48" HIGH MIN.)
 - OSB SHEATHING c/w H CLIPS PRE-ENGINEERED RAISED
 - HEEL WOOD TRUSS (PREFERRED)
 - INSULATION
 - WOOD FURRING
 - AIR & VAPOR RETARDER (WHERE REQUIRED)²
 - GYPSUM BOARD

VENTED METAL SOFFIT

EAVESTROUGH

MINIMUM ROOF INSULATION ABOVE EXTERIOR WALL TO EQUAL VALUE OF WALL INSULATION

SEAL AIR BARRIER (FROM CEILING) TO TYVEK® WRB¹

FOR ADDITIONAL AIR SEALING, WRAP DUPONT™ TYVEK® WRB¹ OVER TOP PLATE TO INTEGRATE WITH INTERIOR AIR BARRIER

TYPICAL WALL ASSEMBLY

- WOOD SIDING
- WOOD FURRING
- TYVEK® WRB¹
- OSB SHEATHING
- WOOD STUDS w/ BATT INSULATION
- VAPOR RETARDER²
- GYPSUM BOARD

¹REFER TO THE FACADE CONSIDERATIONS SECTION OF THE APPLICABLE DUPONT INSTALLATION GUIDELINES TO HELP DETERMINE THE APPROPRIATE TYVEK® WRB FOR THE CLADDING TYPE.

²USE OF INTERIOR VAPOR RETARDER IS DEPENDENT UPON CLIMATE ZONE AND LOCAL BUILDING CODES AND LAWS. CONSULT LOCAL JURISDICTION TO ENSURE APPROPRIATE USE OF VAPOR RETARDERS IN WALL ASSEMBLY.

- NOTES:
- TAPE ALL TYVEK® WRB SEAMS WITH DUPONT™ TYVEK® TAPE.
 - FLASH ALL PENETRATIONS WITH DUPONT SELF-ADHERED FLASHING PRODUCTS.
 - FASTEN TYVEK® WRB TO SHEATHING WITH APPROVED FASTENERS AND CORRECT SPACING OF WRAP CAP STAPLES/NAILS (ex. DUPONT™ TYVEK® WRAP CAP FASTENERS).
 - DO NOT APPLY TYVEK® TAPE OR DUPONT SELF-ADHERED FLASHING PRODUCTS OVER TYVEK® WRAP CAP FASTENERS, OR RECOMMENDED FASTENERS; HOWEVER, FASTENERS CAN BE INSTALLED OVER THE FLASHING.
 - LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERNS OVER MATERIAL SELECTION (ex. SHEATHING TYPE, FRAMING SIZE, INSULATION THICKNESS, ETC.) DETAILING SHOWN ABOVE.



SCALE: NOT TO SCALE
REVISION DATE: 4/19/2022
DRAWING: A25

ROOF/ WALL INTERFACE DETAIL
RESIDENTIAL WOOD FRAME STRUCTURE w/ WOOD SIDING