



ROOF
 ROOFING SHINGLES
 MEMBRANE TYPE EAVE PROTECTION
 (48" HIGH MIN.)
 OSB SHEATHING c/w H CLIPS
 PRE-ENGINEERED RAISED
 HEEL WOOD TRUSS (PREFERRED)
 INSULATION
 WOOD FURRING
 AIR & VAPOR RETARDER (WHERE REQUIRED)²
 GYPSUM BOARD

VENTED METAL SOFFIT
 EAVESTROUGH

MINIMUM ROOF INSULATION
 ABOVE EXTERIOR WALL TO
 EQUAL VALUE OF WALL
 INSULATION

SEAL AIR BARRIER (FROM
 CEILING) TO **TYVEK® WRB**¹

FOR ADDITIONAL AIR SEALING, WRAP
DUPONT™ TYVEK® WRB¹
 OVER TOP PLATE
 TO INTEGRATE WITH INTERIOR AIR
 BARRIER

TYPICAL WALL ASSEMBLY
 FINISH COAT
 BASE COAT w/ EMBEDDED REINFORCING MESH
 RIGID INSULATION
TYVEK® WRB¹
 OSB SHEATHING
 WOOD STUDS w/ BATT INSULATION
 VAPOR RETARDER (WHERE REQUIRED)²
 GYPSUM BOARD

¹REFER TO THE *FACADE CONSIDERATIONS* SECTION OF THE APPLICABLE DUPONT INSTALLATION GUIDELINES TO HELP DETERMINE THE APPROPRIATE **TYVEK® WRB** FOR THE CLADDING TYPE.

²USE OF INTERIOR VAPOR RETARDER IS DEPENDENT UPON CLIMATE ZONE AND LOCAL BUILDING CODES AND LAWS. CONSULT LOCAL JURISDICTION TO ENSURE APPROPRIATE USE OF VAPOR RETARDERS IN WALL ASSEMBLY.

- NOTES:
- TAPE ALL **TYVEK® WRB** SEAMS WITH **DUPONT™ TYVEK® TAPE**.
 - FLASH ALL PENETRATIONS WITH **DUPONT SELF-ADHERED FLASHING PRODUCTS**.
 - FASTEN **TYVEK® WRB** TO SHEATHING WITH APPROVED FASTENERS AND CORRECT SPACING OF WRAP CAP STAPLES/NAILS (ex. **DUPONT™ TYVEK® WRAP CAP FASTENERS**).
 - DO NOT APPLY **TYVEK® TAPE** OR **DUPONT SELF-ADHERED FLASHING PRODUCTS** OVER **TYVEK® WRAP CAP FASTENERS**, OR RECOMMENDED FASTENERS; HOWEVER, FASTENERS CAN BE INSTALLED OVER THE FLASHING.
 - LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERNS OVER MATERIAL SELECTION (ex. SHEATHING TYPE, FRAMING SIZE, INSULATION THICKNESS, ETC.) DETAILING SHOWN ABOVE.
 - INSTALL EIFS ACCORDING TO MANUFACTURER'S WRITTEN INSTRUCTIONS



SCALE: NOT TO SCALE
 REVISION DATE: 4/19/2022
 DRAWING: A75

ROOF/ WALL INTERFACE DETAIL
 RESIDENTIAL WOOD FRAME STRUCTURE w/ EIFS CLADDING