



USE 4" DUPONT™ FLASHING TAPE OR
DUPONT™ STRAIGHTFLASH™ TO
PROTECT TOP EDGE OF METAL DRIP
FLASHING

DUPONT™ FLEXWRAP™ NF LAPPING ONTO FACE
OF WALL MIN. 2"

DUPONT™ FLASHING TAPE OVER FLANGE AND
LAPPING ONTO CEILING OF RECESS MIN. 2"

BUILDING SHEATHING - SEE
DRAWINGS BY OTHERS
CEMENT PLASTER

METAL LATH

INTERVENING LAYER

DUPONT™ TYVEK® WRB

4" DUPONT™ FLASHING TAPE OR
DUPONT™ STRAIGHTFLASH™ TO
TERMINATE

DUPONT™ TYVEK® WRB ONTO THE
METAL DRIP FLASHING

METAL DRIP EDGE (WITHOUT
WEEPS)

DUPONT™ TYVEK® WRB

DUPONT™ TYVEK® TAPE

SET FLANGE IN A FULL BED OF SEALANT

BUILT-IN STUCCO KEY

DUPONT™ RESIDENTIAL SEALANT OR RECOMMENDED SEALANT
WINDOW, SEE DRAWINGS BY OTHERS

2" MIN

NOTES:

1. DETAIL IS FOR RECESSES UP TO 4". SEE SEQUENCING SHEETS FOR ADDITIONAL INSTALLATION GUIDANCE.
2. DETAIL FOR BUILDINGS LESS THAN 5 STORIES AND LOW-RISE MULTI-FAMILY RESIDENTIAL BUILDINGS LESS THAN 6 STORIES WHEN PERFORMANCE REQUIREMENTS DO NOT EXCEED ASTM E1677 (65 MPH EQUIVALENT STRUCTURAL LOAD AND 15 MPH EQUIVALENT WIND-DRIVEN RAIN WATER INFILTRATION), AND WINDOW/DOOR DESIGN RATINGS THAT DO NOT EXCEED DP45.
3. INTERVENING LAYER CAN BE SECOND LAYER OF DUPONT™ TYVEK® WRB, A LAYER OF GRADE D BUILDING PAPER, FELT, RIGID FOAM BOARD OR THE BACKING OF PAPER-BACKED LATH.
4. REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.
5. FASTEN DUPONT™ TYVEK® WRB WITH APPROVED FASTENERS AND SPACING.
6. INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
7. LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN.
8. FOR ADDITIONAL INFORMATION REGARDING PRODUCT INSTALLATION, REFER TO THE APPLICABLE DUPONT™ INSTALLATION GUIDELINE.



SCALE: NOT TO SCALE
REVISION DATE: 11/1/16
DRAWING: R-CP-2171-MA

INTEGRAL FLANGED WINDOW RECESSED GREATER THAN 4" - HEAD
CEMENT PLASTER